


Read this manual carefully before the first use.
For your safety and benefits, please read the manual carefully. We'll NOT take any responsibility if you don't follow our instructions or cautions which result in damage or other loss. Thank you for buying and using our product.




Manufacturer reserves the right of final interpretation



How to turn on/off projector

- Connect power adaptor to the projector, power light on, remove lens cover.
- Press On/Off button for more than 3 sec to turn on the projector
- Press On/Off button twice to turn off the projector




Adjust Focus by Remote



Press Focus button to adjust the image to be clear

Battery of Remote Control

Replace new battery when its power is in low or used up.



How to use the projector

Select the input source
Turn on the devices(PC, laptop,DVD, etc), connect to the projector via HDMI cable, press "Input" button and select "HD"



Paire your devices to projector via Bluetooth:
Turn on the projector and your bluetooth speaker, select "Setting" and enable Bluetooth function, then search and paire with the projector to play music
Caution: The distance between projector and speaker is no more than 10m.



Homepage of the projector:

You'll find the homepage once turn on the projector. It includes 6 categories: Entertainment, Mobile Office, Productivity, App Store, My Apps, Settings. In the meantime, you can add the shortcuts at the bottom of homepage.



WPS

Pre-installed WPS office for Word, Excel, PPT files, portable, easy and simple.
Built-in high-capacity battery, keep away from power cord, last for long time wireless working.



Entertainment

Various of Apps, choose whatever you like.



Shortcuts

Add and remove apps whatever you want




My Apps




Settings

Turn on the projector and select "Settings". It includes 4 categories: Wi-Fi & Networks, Device, Personal and System.



OSD Menu Settings:

Turn on the projector and press "Menu" to find OSD settings It includes: Languages, Input, Image Mode, Sound Mode, Color, Aspect, Rotate, Keystone Correction, Reset, Status, and Software Update(USB)
You can adjust them according to your requirements.



Safety Instructions

The air inlet/outlet/lens should be well ventilated when projector is working, to avoid device damage, fire explosions
Do not drop projector from high falling
Do not put any harzards into the accessories;
Do not open the projector, please contact with professional person for assistant

Do not use projector at below situation:

Wet, dusty, smoky places, or it may pollute optical elements, reduce product life, and projection image will be dark.
Keep minimum (50 mm) space around the appliance for optimal ventilation
The places where temperature is above 35°C;
The places which altitude is more than 3000 meters;

smart Theater & Digital Life

YOUNGTABLE

J20